

COVID-19 Protocol

Equipment Cleaning and Disinfection



We are happy to announce that **A Tempo**, in collaboration with **Motorola Solutions**, has developed a sanitary protocol that guarantees the disinfection of all our equipment, so that we can return to work safe.



CLEANING

- 1 Apply **0.5% detergent-water** solution with a cloth.
- 2 Use a **stiff, non-metallic, short-bristled brush** to work loose dirt away from the device.
- 3 Use a **soft, absorbent, lintless cloth or tissue** to remove the solution and dry the device.

IMPORTANT:

Make sure that no solution remains entrapped near any connectors, cracks or crevices.



DISINFECTING

- 1 Wipe device down with over-the-counter isopropyl alcohol (rubbing alcohol) with **at least 70% alcohol concentration**.
- 2 **Alcohol should never be applied directly** to the device. Apply to a cloth, then wipe down the device.
- 3 The effects of **certain chemicals** and their vapors **can have detrimental effects** on plastics and the metal platings.

IMPORTANT:

Do not use bleach, solvents or cleaning sprays to cleanse or disinfect your device.



The disinfection process that we have implemented in A Tempo consists of three phases:

Cleaning polished surfaces with isopropyl alcohol
Cleaning of electronic equipment using ultraviolet light
Cleaning and purification of the environment in our facilities by means of ozone

We also remind you that the use of PPE is mandatory for our technicians in all A Tempo facilities

If you want more information do not hesitate to contact us